


TruFX Flasher / Sequencer instructions.

The TruFX flasher was made to be easy to operate while providing a wide array of flashing modes.

There are 11 flash rates available with the TruFX504 module:


- Police 1
- Police 2
- EMT 1
- EMT 2
- Alternating 1
- Alternating 2
- Utility 1 (Strobing LED 1)
- Utility 2 (Double Strobing LED 1)
- Lighthouse beacon
- Fire simulation (LED 1 or LED 2)
- Welding simulation (LED 1)



Hooking up the flasher

Hooking up the flasher: The flasher is easy to hookup. Hook both anodes of the LEDs to the common point the circuit board as shown on the picture. Operating voltages are from 7VDC to 15VDC. As usual, connect the red wire to (+) and the black wire to (-) of the DC supply.

Selection of the flash mode is made simply by holding the mode button found at back of the flasher. When the desired flash pattern is reached, simply let go of the button and the flasher will be configured.



Mode selection